1

WARRANTY REGISTRATION

Visit the FLIR / Raymarine website:

- 1. Read the warranty policy.
- 2. Register your product to get 2 years (standard) + 3 years **extended** warranty.




www.bit.ly/osp-warranty


NOTE: Warranty registration must be completed within 90 days of purchase.

2

OBTAIN THE COMPLETE DOCUMENTATION

Visit the FLIR / Raymarine website:







www.bit.lv/osp-docs

3

GETTING STARTED

To start using your camera:

- 1. To charge: use the supplied USB cable to charge the camera via its USB port.
- 2. To switch camera on: hold the **POWER** button for one second.
- 3. To capture an image: **short** press of the **TRIGGER** button.
- 4. To capture a video: **long** press of the **TRIGGER** button.
- 5. To zoom in or out: press the **OPTION** button, ensure that the **Zoom** icon is highlighted in the viewfinder, and then use the **LEFT** or **RIGHT** buttons.

NOTE: If the fitted eyecup does not suit your eye shape, gently pull it away from the viewfinder to remove it, and replace with the alternative eyecup supplied.

4

OBTAIN THE MOBILE APP (Apple iOS only)

The **Scout Pro app** will help you to get the most out of your camera:

- 1. Stream the video from your camera to your phone / tablet.
- 2. View and manage your camera's files on your phone / tablet.

Start the app on your mobile device. Ensure that the **Wireless** switch on the underside of the camera is On. Place the camera close to your mobile device. The app will then guide you through the setup process.



www.bit.ly/scout-pro-app

OPERATION TRIGGER LEFT / RIGHT Short press for Adjust the value for photo; long press the currently selected control mode. for video. **OPTION** POWER Press to select control mode: Hold to power Zoom on or off. Brightness DIOPTER Palettes Twist ring until text and graphics appear sharp. Enable / disable the wireless connection to mobile device. WIRELESS SWITCH Charging. File transfer via PC. USB TYPE-C

CLEA

CLEANING

To ensure optimum image quality, regularly clean the camera body and lens.

For cleaning instructions, refer to the important cleaning information provided in the *Operation Instructions* (71009), available at the following link:



www.bit.ly/osp-docs